

Installation Instructions

Offset **Cushion Coupler**

GOOSENECK EXTENDED CUSHION COUPLERS



PopUp®

Towing Products
Mfg by Young's Products, LLC

4330 S. Johnson Road
Chanute, KS 66720
877-339-5704
info@popuphitch.com

**WARNING: Verify adequate trailer swing clearance
between trailer and cab of truck.**

CC4
4" Round

CC6
4 1/2" Square

CC8
4" Square

1. Remove the stock coupler and tube from the gooseneck trailer coupler receiver tube,
2. Fit the Extended Cushion Coupler REAR TUBE (open tube with holes) into the gooseneck trailer coupler receiver tube. Align the Cushion coupler so the coupler is facing straight forward.
3. Secure your Cushion Coupler in the trailer tube the original set bolts or safety thru pin provided by the trailer manufacturer. Square tube coupler may have a thru pin or a spring loaded pin. Either will work just fine.
4. The three bolts that go thru the cushion are pre-set at the factory and need no further adjustment.
5. Lubricate the inside of the coupler with a thin film of lithium grease.
6. Attach the cable to the coupler lever with a cable clamp. Install eye bolts in the trailer neck to allow the cable to be run to a convenient location near the jack handle. When taking weight off the truck, simply pull the cable to release the coupler from the ball.
7. **CAUTION: Always attach safety chains when towing in the event hitch connections fail.**



Visit us on the web
www.popuphitch.com

